


DIAGNOSTIC CHART




INSPECTION PROCEDURE


1 Check voltage terminal FC.



for M/T



for A/T

BE6653
F16735
F16736

- P** (1) Turn up the floor mat on the passenger side.
(2) Remove the two bolts for engine control module.
(3) Turn ignition switch ON.

- C** Measure voltage between terminal FC of engine control module connector and body ground.

OK Voltage: 9 - 14 V

NG

OK Check and replace engine control module.

2

Check for ECM power source circuit (See page [EG-558](#)).

OK

NG Repair or replace.

Check circuit opening relay.






FIG782
P06249
P06251

- P** (1) Remove center cluster finish lower panel and finish lower center panel.
(2) Remove circuit opening relay.
- C** Check continuity between terminals of circuit opening relay shown below.

OK

Terminals 1 and 2	Open
Terminals 3 and 5	Continuity (Reference value 25Ω)
Terminals 2 and 4	Continuity (Reference value 140Ω)

- C** (1) Apply battery positive voltage between terminals 3 and 5.
(2) Check continuity between terminals 1 and 2.

OK

Terminals 1 and 2	Continuity
-------------------	------------

OK

NG Replace circuit opening relay.

Check for open in harness and connector between main relay and circuit opening relay, circuit opening relay and engine control module (See page IN-27).

OK

NG Repair or replace harness or connector.

Check fuel pump (See page EG-203).

OK

NG Replace fuel pump.

Check for open in harness and connector between circuit opening relay and fuel pump, fuel pump and body ground.

- MEMO -