

Air-gap By-pass Instructions

1. Shut off cold water supply to system.
2. Cut the red & black tubing approximately 4" from the bottom of RO faucet.
3. Cut the 3/8" black tube approximately 6" from the drain saddle.
4. Using a 1/4"X3/8" union connect the 1/4" red tubing from the RO system to the 3/8" black tubing from the drain saddle.
5. Splice in the one way check valve inline of the 1/4" red tube with flow arrow pointing towards the drain saddle.
6. Start-up system and check for leaks.

