







Ref #	Part Number	Qty	Description
1	094163		Seat
2	028X23		Cap, Push On
3	094057		Spring
4	26X229		Screw
5	094160		Bolt, Wing
6	017X47		Washer
7	009X56		Bolt, Shoulder
8	094154E700		Support, Seat
9	094156 Z		Rod, Pivot
10	094153E700		Bracket, Pivot
11	001X45		Bolt
12	015X89		Nut
13	009X55		Bolt, Shoulder
14	094155 Z		Washer
15	164X31		Spring
16	26X249		Screw
17	26X263		Screw
18	164X30		Spring
19	094150E700		Deck, Seat
20	015X88		Nut
21	094194E701		Plate, Index
22	009X47		Screw
23	094109		Mat, Left
24	094108		Mat, Right
25	093215E700		Hood
26	092542		Grille Assembly (Includes Lens)
27	26X239		Screw
28	092539		Lens, Right
29	092541		Brace, Grille
30	0031X4		Pin, Hair
31	26X270		Screw
32	26X238		Screw
33	094219		Bearing, Steering
34	094223		Dash
35	094221E700		Plate, Dash
36	093007E701		Panel, Access
37	095082E701		Support, Dash
38	094013E701		Bracket, Rear Hanger
39	690544E700		Support, Left Grille
40	094007E701		Axle, Hanger
41	690543E700		Support, Right Grille
42	093137 Z		Rod, Pivot
43	690206E700		Frame, Right
44	690207E700		Frame, Left
45	690424		Container, Battery
46	1001002E701		Plate, Hitch
47	690218E700		Plate, Rear
48	094680		Cover, Lift
49	95081E700		Channel
50	092540		Lens, Left
	48X442		Decal, Right Hood
	48X443		Decal, Left Hood
	44X7325		Decal, Warning
	F-000716L		Instruction Book & Parts List



Ref #	Part Number	Qty	Description
1	250X92		Harness, Light Wire
	092372		Socket, Light
	090084		Bulb, Light
2	250X86		Harness, Chassis Wire
3	092377		Switch, Ignition
	020729		Key, Ignition
	091489		Nut, Hex
	091488		Cap, Ignition
4	094136		Switch, Limit
5	054212		Fuse
	407078		Holder, Fuse
6	094613		Solenoid
	26X229		Screw, Mounting
	15X116		Locknut
7	024X32		Cable, Battery Ground
	26X213		Screw, Ground Cable
8	021075		Battery
	002X82		Bolt, Carriage
	014X79		Wingnut
9	250X67		Harness, Seat Switch Wire
10	094159		Switch, Seat Sensor
11	024X31		Cable
12	093156		Ammeter
	250X90		Harness, AC/DC Jumper




Ref #	Part Number	Qty	Description
1	091349		Fuel Cap
2	093148		Fuel Tank
3	095197		Hose Clamp
4	023717		Fuel Line
5	095197		Hose Clamp
6	26X201		Screw
7	094006E700		Plate, Engine
8	093165		Throttle Control
9			Engine Parts are available from and Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.
	095198		Muffler
	095208		Gasket, Muffler
	095200		Liner, Port (Muffler)
10	0025X7		Bolt, Engine Mount
11	690440 Z		Stack Pulley Assembly
12	019X35		Lockwasher
13	01X140		Bolt, Hex
14	17X170		Washer
15	26X249		Screw
16	690401		Choke
17	0019X8		Washer
18	015X33		Nut
19	93188E700		Baffle, Front Engine
20	093078E701		Baffle, Rear Engine
21	094384		Guide, Belt
22	015X79		Nut, Flange
23	091797 Z		Guide, "L" Belt
24	092279		Pipe, Oil Drain
25	021651		Cap, Oil Drain
26	26X253		Screw
27	093077		Spacer
28	025X15		Screw




Ref #	Part Number	Qty	Description
1	26X249		Screw
2	015X84		Nut, Flange
3	093349		Guide, Belt
4	094431E700		Bracket, Idler
5	015X79		Locknut
6	017X47 Z		Washer
7	094417 Z		Rod, Clutch
8	030X20		Pin, Cotter
9	094815		Adjuster
10	094045 Z		Latch, Parking Brake
11	690517 Z		Bracket Assembly, Idler
12	009X39		Bolt, Shoulder
13	095005 Z		Rod, Parking Brake
14	094185E701		Bracket, Transaxle
15	037X61		Belt
16	690409		Pulley, Idler
17	094409 Z		Arm Assembly, Idler
18	690410		Pulley, Idler
19	021544		Pedal
20	690207E700		Frame, Left
21	690206E700		Frame, Right
22	015X88		Nut, Flange
23	165X142		Spring, Extension
24	094428 Z		Rod, Disconnect
25	094429E700		Bracket, Disconnect
26	002X53		Bolt, Carriage
27	26X216		Screw
28	094432E700		Strap, Right Torque
29	094426 Z		Rod, Link
30	0031X4		Pin, Hair
31	0031X6		Pin, Hair
32	092132		Nut, Adjuster
33	094425E700		Rod, Yoke
34	165X115		Spring, Extension
35	17X169		Washer
36	094035E700		Bracket, Pivot
37	094038E700		Lever, Clutch/Brake
38	094433E700		Strap, Left Torque
39	094424 Z		Rod, Link
40	091079		Grip
41	690013E700		Pedal, Speed Control
42	17X148		Washer
43	094430 Z		Arm, Disconnect
44	165X112		Spring
45	06X105		Bolt
46	690369		Spacer
47	017X38		Washer
48	17X169		Washer
49			Transaxle For information on Replacement Parts see the Central Parts Distributor in your area.
50	021553		Key, Square
51	094184E701		Bracket, Right Transaxle
52	01X155		Bolt
53	165X92		Spring, Extension
54	094434E700		Clamp, Transaxle
55	17X160		Washer
56	690554 Z		Spacer

Ref #	Part Number	Qty	Description
57	17X195		Washer
58	0011X3		E-Ring
59	024373		Valve Stem
60	92511-601		Wheel & Tire Assembly
61	407926		Tire
	407049		Tube
62	094618		Cap, Hub
63	015X98		Nut




Ref #	Part Number	Qty	Description
1	094199		Pulley, Jackshaft
2	15X121		Nut, Hex
3	037X88		Belt, Mower Drive
4	690387		Pulley, Idler
5	015X84		Nut, Flange
6	094129		Jackshaft
7	094130		Spacer
8	690212E700		Link, Lift
9	094137		Pad, Friction
10	009X52		Bolt, Shoulder
11	094055E701		Bracket, Suspension
12	094049E701		Pad Assembly, Left Brake
13	094068		Knob
14	009X51		Bolt, Shoulder
15	094128E700		Plate, Suspension
16	166X43		Spring
17	015X79		Nut, Flange
18	094192E700		Bracket, Suspension
19	94194		Pin, Hanger
20	17X103		Washer
21	0031X4		Pin, Hair
22	0025X7		Bolt
23	094051E701		Cover, Pulley
24	009X39		Bolt, Shoulder
25	690408E700		Arm, Idler
26	166X41		Spring
27	094047E701		Pad Assembly, Right Brake
28	094193E701		Bracket, Brake
29	166X42		Spring
30	094191E700		Bracket, Suspension
31	092426E701		Plate
32	015X88		Nut, Flange
33	002X53		Bolt, Carriage
34	092574		Mandrell Housing
35	690539E701		Bracket, Suspension
36	092466		Adapter, Blade
37	095100E701		Blade
38	17X166		Washer
39	17X165		Washer
40	15X100		Nut
41	0166X4		Spring
42	028X23		Cap, Push On
43	094957 Z		Rod, Deflector
44	094707SE		Deflector Assembly
45	094956E701		Bracket, Deflector Hinge
46	094686E700		Bracket, Front Hanger
47	017X45 Z		Washer
48	094781		Guide, Belt
49	690369		Spacer
50	094025		Bolt, Axle
51	017X91 Z		Washer
52	165X119		Spring, Extension
53	092683		Wheel, Gage
54	1001260E701		Bracket, Right Wheel
55	092423E700		Bracket, Left Wheel
57	26X249		Screw
58	094604E700		Stiffener

Ref #	Part Number	Qty	Description
59	094814E701		Housing, Blade Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 53, 54, 55, and 56.
60	031X11		Ring, Locking
	776007		Complete Mower Housing Assembly Includes Key No. 1-60
61	095080E701		Plate, Mulcher
62	002X64		Bolt, Carriage
63	014X86		Wingnut



Ref #	Part Number	Qty	Description
1	092698		Grip
2	094100 Z		Handle, PTO
3	094022 Z		Pad, Switch
4	0025X3		Bolt
5	092697		Grip
6	166X40		Spring
7	17X103		Washer
8	690533		Lever, Lift
9	094017 Z		Lever, PTO
10	009X39		Bolt, Shoulder
11	030X20		Pin, Cotter
12	17X102		Washer
13	094004 Z		Link, PTO
14	015X84		Nut, Flange
15	26X249		Screw
16	166X39		Spring
17	094018E701		Bracket, PTO
18	165X119		Spring
19	690394E700		Crank, PTO
20	690212E700		Link, Lift
21	690122E700		Link, Lift Handle
22	17X168		Washer
23	017X57		Washer
24	0031X4		Pin, Hair
25	017X91 Z		Washer
26	002X85		Bolt, Carriage
27	690363E700		Lever Assembly, Lift
30	094067		Pin
31	094055E701		Bracket, Rear Suspension
32	690151		Spacer, Lifter
33	009X53		Bolt, Shoulder
34	094015E700		Bracket, Pivot
36	17X191		Washer
37	015X84		Nut, Flange
38	165X131		Spring
39	015X68		Nut, Flange
40	094005E700		Bracket, PTO
41	094027E701		Hanger, Left Deck
42	094026E701		Hanger, Right Deck
43	094158 Z		Rod, Hanger
44	690539E701		Bracket, Suspension
45	690389E700		Plate, Stiffening



Ref #	Part Number	Qty	Description
1	095185		Wheel, Steering
2	690626		Post, Steering
3	711326		Insert, Steering Wheel
4	094124		Bearing
5	15X111		Nut, Flange
6	009X57		Bolt, Shoulder
7	690183		Gear, Pinion
8	011X25		Ring, Snap
9	094121		Gear, Sector
10	094123		Bearing
11	001X84		Bolt
12	690551E700		Plate, Steering
13	94006		Plate, Engine
14	015X88		Nut, Flange
15	15X118		Nut, Flange
16	094013E701		Bracket, Hanger
17	094007E701		Axle, Hanger
18	01X146		Bolt
19	030X49		Pin, Cotter
20	690150		Bearing
21	094576E701		Spindle Assembly, Left
22	01X111		Bolt
23	17X104		Washer
24	017X53 Z		Washer
25	015X84		Nut, Flange
26	690210E700		Axle Assembly
27	095329E701		Drag Link, Left
28	094575E701		Spindle Assembly, Right
29	095328E701		Drag Link, Right
30	26X249		Screw
31	091334		Bearing, Wheel
32	024373		Stem, Valve
33	024380		Tire
	407924		Tube
34	94581-601		Wheel and Tire Assembly
35	17X195		Washer
36	17X192		Washer
37	17X113		Washer
38	094618		Hub Cap
39	26X267		Screw
40	092059		Bellows
41	0025X3		Bolt
43	17X146 Z		Washer