

Illustrated Index



NOTE:

- Whenever the transmission is removed, release bearing sliding surface should be cleaned and greased.
- If the * mark parts were removed, the clutch hydraulic system must be bled.

