







Ref #	Part Number	Qty	Description
1	094162		Seat
2	028X23		Cap, Push On
3	094057		Spring
4	26X229		Screw
5	094160		Bolt, Wing
6	017X47		Washer
7	009X56		Bolt, Shoulder
8	094154E700		Support, Seat
9	094156 Z		Rod, Pivot
10	094153E700		Bracket, Pivot
11	001X45		Bolt
12	015X89		Nut
13	009X55		Bolt, Shoulder
14	094155 Z		Washer
15	164X31		Spring
16	26X249		Screw
17	26X263		Screw
18	164X30		Spring
19	095249E245		Deck, Seat
20	015X88		Nut
21	094829E700		Plate, Index
23	094999		Mat, Left
24	094998		Mat, Right
25	094072E245		Hood
26	094079E701		Grille
27	094081		Lens, Left
28	094807 Z		Bezel
29	094080		Lens, Right
30			UNKNOWN
31	26X270		Screw
32	26X239		Screw
33	094075		Bearing, Steering
34	094074E700		Dash
35	26X250		Screw
36	093007E701		Panel, Access
37	095318E701		Support, Dash
38	094013E701		Bracket, Rear Hanger
39	094083E700		Support, Left Grille
40	094007E701		Axle, Hanger
41	094082E700		Support, Right Grille
42	009X51		Bolt, Shoulder
43	690206E700		Frame, Right
44	690207E700		Frame, Left
45	094069		Container, Battery
46	1001002E701		Plate, Hitch
47	094023E700		Panel, Rear
	F-99701		Book, Instruction



Ref #	Part Number	Qty	Description
1	250X68		Harness, Light Wire
	092372		Socket, Light
	090084		Bulb, Light
2	250X86		Harness, Chassis Wire
3	092377		Switch, Ignition
	020729		Key, Ignition
	091489		Nut, Hex
	091488		Cap, Ignition
4	094136		Switch, Limit
5	054212		Fuse
	407078		Holder, Fuse
6	094613		Solenoid
	26X229		Screw, Mounting
	15X116		Locknut
7	024X32		Cable, Battery Ground
	26X213		Screw, Ground Cable
8	021075		Battery
	002X82		Bolt, Carriage
	014X79		Wingnut
9	250X67		Harness, Seat Switch Wire
10	094159		Switch, Seat Sensor
11	024X31		Cable




Ref #	Part Number	Qty	Description
1	092317		Fuel Cap
2	094073		Fuel Tank
3	095197		Hose Clamp
4	023717		Fuel Line
5	095197		Hose Clamp
6	26X201		Screw
7	094006E700		Plate, Engine
8	091989		Throttle Control
9			Engine Parts are available from a Briggs & Stratton Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.
10	0025X7		Bolt, Engine Mount
11	094139 Z		Stack Pulley Assembly
12	019X35		Lockwasher
13	01X140		Bolt, Hex
14	17X170		Washer
15	26X249		Screw
16	091309		Gasket
17	091271		Muffler
18	094099 Z		Deflector, Muffler
19	26X208		Screw
20	01X134		Bolt, Hex
21	093349		Guide, Belt
22	015X79 Z		Nut, Flange
23	094066		Guide, Belt
24	091277		Shield, Heat
26	26X253		Screw




Ref #	Part Number	Qty	Description
1	009X39		Bolt, Shoulder
2	015X89		Nut, Hex
3	094040 Z		Arm, Idler
4	094041 Z		Rod, Clutch
5	015X79		Nut
6	17X102		Washer
7	092697		Grip
8	030X20		Pin, Cotter
9	094043 Z		Lever, Shift
10	017X47 Z		Washer
11	094044 Z		Link, Shift
12	021920		Nut, Adjuster
13	091079		Grip
14	094152 Z		Rod, Parking Brake
15	094815		Nut, Adjuster
16	094034E700		Bracket, Shift
17	26X249		Screw
18	015X84		Nut
19	094042 Z		Link
20	009X54		Bolt, Shoulder
21	165X116		Spring, Extension
22	094033E700		Bracket, Shifter
23	690206E700		Frame, Right
24	025X12		Screw
25	690207E700		Frame, Left
26	094045 Z		Latch, Parking Brake
27	021544		Pedal
28	094038E700		Lever, Brake/Clutch
29	094035E700		Bracket, Pedal
30	037X87		Belt, Motion Drive
31	094031 Z		Yoke, Shift
32	0031X6		Pin, Hair
33	17X148		Washer
34	018X32		Washer
35	01X145		Bolt
36			Transaxle For information on Replacement Parts see the Central Parts Distributor in your area.
37	015X88		Nut
38	020697		Key, Woodruff
39	01X155		Bolt
40	094008E701		Bracket, Transaxle
41	091179		Pulley
42	094132		Spacer
43	0011X7		E-Ring
44	095094		Pulley, Drive
45	021553		Key, Square
46	17X160		Washer
47	87X105 Z		Spacer, Transaxle
48	024373		Stem, Valve
49	091923		Tire
	407049		Tube
50	092288-601		Wheel & Tire Assembly
51	17X195		Washer
52	0011X3		E-Ring
53	094618		Hub Cap (Optional)
54	093349		Guide, Belt
55	0031X4		Pin, Hair


Ref #	Part Number	Qty	Description
56	165X115		Spring, Extension
57	165X92		Spring, Extension



Ref #	Part Number	Qty	Description
1	092851		Pulley, Jackshaft
2	15X121		Nut, Hex
3	037X62		Belt, Mower Drive
4	091801		Pulley, Idler
5	015X84		Nut, Flange
6	094129		Jackshaft
7	094130		Spacer
8	094053E701		Link, Lift
9	094137		Pad, Friction
10	009X52		Bolt, Shoulder
11	094055E701		Bracket, Suspension
12	094049E701		Pad Assembly, Left Brake
13	094068		Knob
14	009X51		Bolt, Shoulder
15	094128E700		Plate, Suspension
16	166X43		Spring
17	015X79		Nut, Flange
18	094143E700		Bracket, Suspension
19	094064		Pin, Hanger
20	17X103		Washer
21	0031X4		Pin, Cotter
22	0025X7		Bolt
23	094051E701		Cover, Pulley
24	009X39		Bolt, Shoulder
25	094177 Z		Arm, Idler
26	166X41		Spring
27	094047E701		Pad Assembly, Right Brake
28	094145E700		Bracket Assembly, Brake
29	166X42		Spring
30	094142E700		Bracket, Suspension
31	091770E700		Plate
32	015X88		Nut, Flange
33	002X53		Bolt, Carriage
34	090905		Mandrell
35	690539E701		Bracket, Suspension
36	092466		Adapter, Blade
37	092002E701		Blade
38	17X166		Washer
39	17X165		Washer
40	15X100		Nut
41	0166X4		Spring
42	028X23		Cap, Push On
43	094957 Z		Rod, Pivot
44	094707		Deflector Assembly
45	91765E700		Bracket, Deflector
46	094144E700		Bracket, Front Hanger
47	017X45 Z		Washer
48	094781		Guide, Belt
49	094611E701		Link, Left Lift
50	094681E700		Bracket, Support
51	26X249		Screw
52	165X119		Spring, Extension
53	094888E700		Housing, Blade Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 47, and 51.
1-53	776001		Complete Mower Housing Assembly



Ref #	Part Number	Qty	Description
1	092698		Grip
2	094157 Z		Handle
3	094022 Z		Pad, Switch
4	0025X3		Bolt
5	092697		Grip
6	166X40		Spring
7	17X103		Washer
8	94180 Z		Lever, Lift
9	094017 Z		Lever, PTO
10	009X39		Bolt, Shoulder
11	030X20		Pin, Cotter
12	17X102		Washer
13	094004 Z		Link, PTO
14	015X84		Nut, Flange
15	26X249		Screw
16	166X39		Spring
17	094018E701		Bracket, PTO
18	165X119		Spring
19	94019E700		Crank, PTO
20	094611E701		Link, Left Lift
21	094028 Z		Link, Lift
22	001X74		Bolt
23	026X49		Screw
24	0031X4		Pin, Hair
25	017X91 Z		Washer
26	094053E701		Link, Right Lift
27	094180E700		Lever Assembly, Lift
28	15X118		Nut, Flange
29	094030E700		Plate, Lift Arm
30	094067		Pin
31	094055E701		Bracket, Rear Suspension
32	094065		Bushing
33	009X53		Bolt, Shoulder
34	094015E700		Bracket, Pivot
35	094063E700		Tube, Deck Lift
36	17X191		Washer
37	015X84		Nut, Flange
38	165X117		Spring
39	015X68		Nut, Flange
40	094005E700		Bracket, PTO
41	094027E701		Hanger, Left Deck
42	094026E701		Hanger, Right Deck
43	094158 Z		Rod, Hanger
44	690539E701		Bracket, Suspension



Ref #	Part Number	Qty	Description
1	095336		Wheel, Steering
2	094520		Post, Steering
3	095338		Insert, Steering Wheel
4	094124		Bearing
5	15X113		Nut, Flange
6	009X57		Bolt, Shoulder
7	690183		Gear, Pinion
8	011X25		Ring, Snap
9	094121		Gear, Sector
10	094123		Bearing
11	001X84		Bolt
12	690167E700		Plate, Steering
13	094006E700		Plate, Engine
14	015X88		Nut, Flange
15	15X118		Nut, Flange
16	094013E701		Bracket, Hanger
17	094007E701		Axle, Hanger
18	01X146		Bolt
19	030X49		Pin, Cotter
20	092527		Bearing
21	094576E701		Spindle Assembly, Left
22	01X111		Bolt
23	17X104		Washer
24	017X53 Z		Washer
25	015X84		Nut, Flange
26	94012E700		Axle Assembly
27	095329E701		Drag Link, Left
28	094575E701		Spindle Assembly, Right
29	095328E701		Drag Link, Right
30	26X249		Screw
31	091334		Bearing, Wheel
32	024373		Stem, Valve
33	091912		Tire
	407924		Tube
34	094578-601		Wheel and Tire Assembly
35	17X195		Washer
36	17X192		Washer
37	17X113		Washer
38	094618		Hub Cap
39	26X267		Screw
40	092059		Bellows
41	01X158		Bolt
42	018X32		Lockwasher
43	17X146 Z		Washer