







Ref #	Part Number	Qty	Description
1	094163		Seat
2	028X23		Cap, Push On
3	094057		Spring
4	26X229		Screw
5	1001054		Bolt, Wing
6	017X47		Washer
7	009X56		Bolt, Shoulder
8	094154E700		Support, Seat
9	094156 Z		Rod, Pivot
10	094153E700		Bracket, Pivot
11	001X45		Bolt
12	015X89		Nut
13	009X55		Bolt, Shoulder
14	094155 Z		Washer
15	164X31		Spring
16	26X249		Screw
17	26X263		Screw
18	164X30		Spring
19	095122E276		Deck, Seat
20	015X88		Nut
21	094151E700		Plate, Index
22	009X47		Screw
23	094999		Mat, Left
24	094998		Mat, Right
25	690608E276		Hood
26	094079E701		Grille
27	094081		Lens, Left
28	094807 Z		Bezel, Left
29	094080		Lens, Right
30	094807 Z		Bezel, Right
31	26X270		Screw
32	26X238		Screw
33	094075		Bearing, Steering
34	094074E700		Dash
35	015X84		Nut
36	093007E701		Panel, Access
37	095318E701		Support, Dash
38	094013E701		Bracket, Rear Hanger
39	094083E700		Support, Left Grille
40	094007E701		Axle, Hanger
41	094082E700		Support, Right Grille
42	009X58		Bolt, Shoulder
43	1001022E700		Frame, Right
44	1001023E700		Frame, Left
45	690424		Container, Battery
46	1001002E700		Plate, Hitch
47	690434E700		Panel, Rear
48	094610		Cover, Level Adjustment
	48X461		Decal, Right Hood
	48X462		Decal, Left Hood
	44X7325		Decal, Warning
	F-000782L		Instruction Book & Parts List




Ref #	Part Number	Qty	Description
1	250X92		Harness, Light Wire
	092372		Socket, Light
	090084		Bulb, Light
2	250X87		Harness, Chassis Wire
3	092556		Switch, Ignition
	020729		Key, Ignition
	091489		Nut, Hex
	091488		Cap, Ignition
4	094136		Switch, Limit
5	054212		Fuse
	407078		Holder, Fuse
6	094613		Solenoid
	26X229		Screw, Mounting
	15X116		Locknut
7	024X32		Cable, Battery Ground
	26X213		Screw, Ground Cable
8	021075		Battery
	002X82		Bolt, Carriage
	014X79		Wingnut
9	250X67		Harness, Seat Switch Wire
10	094159		Switch, Seat Sensor
11	024X31		Cable



Ref #	Part Number	Qty	Description
1	092317		Fuel Cap
2	094073		Fuel Tank
3	095197		Hose Clamp
4	023717		Fuel Line
5	095197		Hose Clamp
6	26X201		Screw
7	094006E700		Plate, Engine
8	091989		Throttle Control
9			Engine
	690436		Muffler
	1001053		Clip, Locking
	091309		Gasket, Muffler
	095207		Adapter, Muffler
	06X103		Screw, Adapter
	009X59		Bolt, Muffler
10	0025X7		Bolt, Engine Mount
11	690439 Z		Stack Pulley Assembly
12	019X35		Lockwasher
13	01X140		Bolt, Hex
14	17X170		Washer
15	26X249		Screw
21	094384		Guide, Belt
22	015X79		Nut, Flange
23	094066		Guide, Belt
26	26X253		Screw
30	094324		Shield, Heat
31	26X263		Screw




Ref #	Part Number	Qty	Description
1	1001025 Z		Rod, Roll Release
2	26X249		Screw
3	690237		Bracket, Disconnect
4	165X92		Spring, Extension
5	1001018 Z		Assembly, Idler Arm
6	002X92		Bolt, Carriage
7	1001005E700		Bracket, Idler Pivot
8	1001012		Bushing, Pivot
9	690410		Pulley, Idler
10	015X98		Nut, Flange
11	690409		Pulley, Idler
12	690369		Spacer
13	1001014		Nut, Tee
14	094008E701		Bracket, Transaxle
15	091079		Grip
16	094152 Z		Rod, Parking Brake
17	094045 Z		Latch, Parking Brake
18	1001013 Z		Rod, Parking Brake
19	1001007 Z		Link, Clutch
20	009X49		Bolt, Shoulder
21	37X106		Belt, Drive
22	015X79		Nut, Flange
23	021544		Pedal
24	094384		Guide, Belt
25	1001019		Assembly, Control Rod
26	002X53		Bolt, Carriage
27	015X88		Nut, Flange
28	0031X4		Pin, Hair
29	1001072		Pedal, Speed Control
30	1001011		Assembly, Brake Pedal
31	030X20		Pin, Cotter
32	017X48		Washer
33	165X92		Spring, Extension
34	002X88		Bolt, Carriage
35	165X145		Spring, Brake
36	1001004		Strap, Torque
37	015X84		Locknut
38	01X155		Bolt
39	002X78		Bolt, Carriage
40	165X144		Spring, Clutch
41			Transmission For information on Replacement Parts see the Central Parts Distributor in your area.
42	021553		Key, Square
43	17X160		Washer
44	1001043 Z		Spacer
45	17X195		Washer
46	1001023E700		Frame, Left
47	1001022E700		Frame, Right
48	011X23		E-Ring
49	094618		Cap, Hub (Optional)
50	092290-601		Wheel & Tire Assembly
51	092374		Tire
	407049		Tube
52	024373		Stem, Valve




Ref #	Part Number	Qty	Description
1	094199		Pulley, Jackshaft
2	15X121		Nut, Hex
3	037X88		Belt, Mower Drive
4	690387		Pulley, Idler
5	015X84		Nut, Flange
6	094129		Jackshaft
7	094130		Spacer
8	690212E700		Link, Lift
9	094137		Pad, Friction
10	009X52		Bolt, Shoulder
11	094055E701		Bracket, Suspension
12	094049E701		Pad Assembly, Left Brake
13	094068		Knob
14	009X51		Bolt, Shoulder
15	094128E700		Plate, Suspension
16	166X43		Spring
17	015X79		Nut, Flange
18	094192E700		Bracket, Suspension
19	94194		Pin, Hanger
20	17X103		Washer
21	0031X4		Pin, Hair
22	0025X7		Bolt
23	094051E701		Cover, Pulley
24	009X39		Bolt, Shoulder
25	690408E700		Arm, Idler
26	166X41		Spring
27	094047E701		Pad Assembly, Right Brake
28	094193E701		Bracket, Brake
29	166X42		Spring
30	094191E700		Bracket, Suspension
31	092426E701		Plate
32	015X88		Nut, Flange
33	002X53		Bolt, Carriage
34	092574		Mandrell Housing
35	690539E701		Bracket, Suspension
36	092466		Adapter, Blade
37	095100E701		Blade
38	17X166		Washer
39	17X165		Washer
40	15X100		Nut
41	0166X4		Spring
42	028X23		Cap, Push On
43	094957 Z		Rod, Deflector
44	094707SE		Deflector Assembly
45	094956E701		Bracket, Deflector Hinge
46	094686E700		Bracket, Front Hanger
47	017X45 Z		Washer
48	094781		Guide, Belt
49	690369		Spacer
50	094025		Bolt, Axle
51	017X91 Z		Washer
52	165X119		Spring, Extension
53	092683		Wheel, Gage
54	1001260E701		Bracket, Right Wheel
55	092423E700		Bracket, Left Wheel
57	26X249		Screw
58	094604E700		Stiffener

Ref #	Part Number	Qty	Description
59	094814E701		Housing, Blade Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 53, 54, 55, and 56.
60	031X11		Ring, Locking
	776007		Complete Mower Housing Assembly Includes items 1-60



Ref #	Part Number	Qty	Description
1	092698		Grip
2	094157 Z		Handle, PTO
3	094022 Z		Pad, Switch
4	0025X3		Bolt
5	092697		Grip
6	166X40		Spring
7	17X103		Washer
8	690533		Lever, Lift
9	094017 Z		Lever, PTO
10	009X39		Bolt, Shoulder
11	030X20		Pin, Cotter
12	17X102		Washer
13	094004 Z		Link, PTO
14	015X84		Nut, Flange
15	26X249		Screw
16	166X39		Spring
17	094018E701		Bracket, PTO
18	165X119		Spring
19	690394E700		Crank, PTO
20	690212E700		Link, Lift
21	690122E700		Link, Lift Handle
22	17X168		Washer
23	017X57		Washer
24	0031X4		Pin, Hair
25	017X91 Z		Washer
26	002X85		Bolt, Carriage
27	690363E700		Lever Assembly, Lift
30	094067		Pin
31	094055E701		Bracket, Rear Suspension
32	690151		Spacer, Lifter
33	009X53		Bolt, Shoulder
34	094015E700		Bracket, Pivot
36	17X191		Washer
37	015X84		Nut, Flange
38	165X131		Spring
39	015X68		Nut, Flange
40	094005E700		Bracket, PTO
41	094027E701		Hanger, Left Deck
42	094026E701		Hanger, Right Deck
43	094158 Z		Rod, Hanger
44	690539E701		Bracket, Suspension
45	690389E700		Plate, Stiffening



Ref #	Part Number	Qty	Description
1	094134		Wheel, Steering
2	690625		Post, Steering
3	094131		Clip, Retainer
4	094124		Bearing
5	15X111		Nut, Flange
6	009X57		Bolt, Shoulder
7	690183E700		Gear, Pinion
8	011X25		Ring, Snap
9	094121		Gear, Sector
10	094123		Bearing
11	001X84		Bolt
12	1001024E700		Plate, Steering
13	094006E700		Plate, Engine
14	015X88		Nut, Flange
15	15X118		Nut, Flange
16	094013E701		Bracket, Hanger
17	094007E701		Axle, Hanger
18	01X146		Bolt
19	030X49		Pin, Cotter
20	690150		Bearing
21	094576E701		Spindle Assembly, Left
22	01X111		Bolt
23	17X104		Washer
24	017X53 Z		Washer
25	015X84		Nut, Flange
26	690210E700		Axle Assembly
27	095329E701		Drag Link, Left
28	094575E701		Spindle Assembly, Right
29	095328E701		Drag Link, Right
30	26X249		Screw
31	091334		Bearing, Wheel
32	024373		Stem, Valve
33	091912		Tire
	407047		Tube
34	094579-601		Wheel and Tire Assembly
35	17X195		Washer
36	17X192		Washer
37	17X113		Washer
38	094618		Hub Cap (Optional)
39	26X267		Screw
40	092059		Bellows (Optional)