



## RELAY LOCATIONS


### [Engine Compartment]



### [Body] [STATION WAGON]




# [Instrument Panel] [SEDAN-WAGON-STATION WAGON]




# RELAY LOCATIONS


○ : J/B No. 1      Left Kick Panel      (See Page 19)



\*1: STATION W/G  
\*2: EX. STATION W/G





[J/B No. 1 Inner Circuit]




# RELAY LOCATIONS

○ : J/B No. 2      Engine Compartment Left (See Page 18)




## [J/B No. 2 Inner Circuit]



## RELAY LOCATIONS

○ : J/B No. 3      Instrument Panel Left (See Page 19)




### [J/B No. 3 Inner Circuit]



④ : R/B No. 4

Right Kick Panel

(See Page 19)




⑤ : R/B No. 5

Engine Compartment Left

(See Page 18)

[USA]



[CANADA]

